



















Anleitung




WF306309AAW





Tools Recommended











A 12PCS 	B 12PCS 	C 12PCS 	D 2SET  3*16	E 4PCS 	F 16PCS  3.5*14	G 2SET  3*10	H 4SET  3.5*14
I 1PCS  3*12	J 16PCS 	K 12PCS 	L 1SET  4*16	 4*35	M 1PCS 		



- A 6PCS 
- B 6PCS 
- C 6PCS 






- D 2SET 













6





- J 16PCS 
- K 12PCS 